


BREAK-AWAY OCTAGON ARM KIT for a 1601 / 1602


DoorKing Part Number
8080-295

This kit is designed for the 1601 **OR** a 1602 with a 17 ft arm **ONLY** barrier gate operators. It **CANNOT** be used with a 1603 auto-spikes, 1620 lane barrier or 1625 wedge barrier. The kit provides a **break-away bracket assembly** for a **OCTAGON arm** with **OR** without **Reverse/LED edge**, sold separately. Arm will reverse if lowering and an obstruction is encountered. If the arm is struck and breaks away (will pivot in **ONE DIRECTION ONLY**, see below), gate operator will **automatically** shut down. The arm manually snaps back into the release rollers to function normally again. **NO reset** is necessary.




Break-Away OCTAGON Arm Bracket Direction Options

Break-Away arm bracket will only pivot in **ONE DIRECTION** depending on which way the break-away arm bracket is installed.




Option #1

Arm breaks **AWAY** from operator cabinet



Option #2

Arm breaks **TOWARDS** operator cabinet



OCTAGON ARM ONLY



120 S. Glasgow Avenue
Inglewood, California 90301 U.S.A.


Copyright 2026 DoorKing®, Inc. All rights reserved.

Break-Away OCTAGON Arm Bracket Installation Steps:

1 Install Hub	2
2 Install Break-Away Bracket	3
3 Install Arm (Octagon)	4
4 Install Wire Harness (8080-356)	4
5 Attach Wire Harness to Break-Away Bracket	5
6 Mount Power Supply and Relay	6
7 Connect Wire Harness to Operator . . . and Wiring OPTIONS	7
8 Connect Arm to Wire Harness	8
9 Secure Wires to Break-Away Bracket	8
10 Break-Away Arm Reset Procedure	8
• 2-Ft Coupler Installation (Required) (Included)	9
• 14 Ft 2-Piece Arm Assembly (Optional) (Sold Separately)	10
• Reverse Edge or Reverse/LED Edge Installation (Optional) (Sold Separately)	11
• 14 Ft Rubber Bumper Installation (Optional) (Sold Separately)	12
• Shortening a Octagon Arm to 7 Ft, 8 Ft, 11 Ft (If Using Shorter Length Reverse Edge)	13
• 17 Ft Octagon Arm Assembly for a 1602 ONLY (Optional) (Sold Separately)	14
Older Existing Arm Plastic Cover Modification (If Necessary)	15



1 Install Hub

AFTER the barrier operator has been **PERMANENTLY INSTALLED** and has **POWER**, insert hub and secure it as shown to **YOUR DESIRED** side of the operator. A **SINGLE HUB** should be mounted on the **SAME** side as **ONCOMING** traffic.





Break-Away Arm Direction Options

Arm will only pivot in **ONE DIRECTION** depending on which way the break-away arm bracket is installed. **Choose the desired break-away direction** and install break-away arm bracket accordingly (note position of **arm pivot bolt** and release rollers).




2 Install Break-Away Bracket



IMPORTANT Test the hub's **UP** and **DOWN** positions on the operator **BEFORE** installing arm bracket.
TURN OFF POWER BEFORE INSTALLING BRACKET

3 Install Arm

Drawings NOT to scale



Arm sleeve snaps into release rollers.

3/8" Arm Pivot Bolt

3/8" Arm Pivot Bolt

Option #2

Arm breaks TOWARDS operator cabinet

Option #1


Arm breaks AWAY from operator cabinet

OCTAGON Arm Options:

- 14 Ft 1-piece arm: Optional Edge See page 11
- 14 Ft 2-piece arm: See page 10
- 17 Ft arm: See page 14

IMPORTANT 2-Ft Coupler MUST be installed inside the end of the Octagon arm for stiffness, see below and page 9.

Drill a .375" Pivot Hole in Arm



Align coupler and arm together to mark and drill a .375" hole thru top and bottom of arm depending on your arm pivot choice. Slide coupler in end of arm until the arm hole you drilled aligns with the corresponding coupler hole.

Tip: Liquid soap will help coupler slide in easier.

If Shortening Arm see page 13

4 Install Wire Harness (8080-356)


Choose which side of the operator the arm is mounted on, remove knock-out and run wire harness accordingly as shown.

Wire Harness Run Options

Wire harness can run from **EITHER** side of the **operator** depending on which side the arm is mounted on. “**NEAR**” and “**FAR**” side refers to the electronic box’s relative distance from **YOUR** chosen arm’s mounting side of operator.

IMPORTANT: Allow slack in the wire harness between the cable grips of at least 13” or more for the rotating arm.

See page 8 for arm connection options.




IMPORTANT: Allow slack in the wire harness between the cable grips of at least 13” or more for the rotating arm.

Note for Older Operators: A 5/8” hole will have to be drilled in the operator cabinet **approximately** where Knock-Out is shown. Make sure 5/8” hole is clear of all internal components.

5 Attach Wire Harness to Break-Away Bracket


Option #1



Attach wire harness to **BOTTOM** hole in back end of break-away bracket with **cable grip** for **either** option.

See page 8 for arm connection **options** and **securing wires** to break-away bracket.


6 Mount Power Supply and Relay



7 Connect Wire Harness to Operator ... and Wiring OPTIONS

MAKE SURE ALL POWER IS TURNED OFF TO OPERATOR!

Convenience Open 1473 On SOME Model Operators




Note: Break-Away arm will NOT allow a tailgating vehicle with older model barrier operator with 2340-010 convenience open circuit board.

OPTIONAL DKS Pedestrian Protection System Set-up



Note: The arm will NOT allow a tailgating vehicle unauthorized entry, BUT helps protect pedestrians from a lowering arm when they are in the arm's swing path. (Sold Separately)

Devices Required:
 Plug-in Single Channel Loop Detector with Auxiliary Relay P/N 9411-010
 DKS Photocell P/N 8080-057
 See 1601-065 PDF for more info when used.
HIGHLY Recommended



Note: The traffic light is wired together with the break-away arm in some installations when desired, so it's shown here for wiring reference. See Traffic Light 1603-264 PDF for more info when used.


Recommended
 P/N 1603-221 6 Ft Cable/No Post
 P/N 1603-222 6 Ft Cable/35" Post
 P/N 1603-223 11 Ft Cable/95" Post




Make sure ANY unused wires (Example: Convenience open NOT on your operator so wires are not used) are properly terminated and do NOT have exposed bare wires or metal connectors that could cause the operator to malfunction.

8 Connect Arm to Wire Harness

MAKE SURE ALL POWER IS TURNED OFF TO OPERATOR!



9 Secure Wires to Break-Away Bracket



IMPORTANT: To secure wires to bracket, allow for some slack in the wires to account for the arm pivoting when arm "Breaks Away" from bracket. Test breakaway feature to **make sure** there is enough slack in the wires when securing wires. Make sure **plastic arm cover** will fit over the wires and it doesn't **RUB** any wires during operation.


10 Break-Away Arm Reset Procedure

If arm gets struck and breaks away, gate operator will automatically shut down (Break-away sensors are tripped). Snap arm back into the release rollers. Make sure all wires are out of the way of the arm when snapping arm back in position. **NO Reset is necessary.** Normal operation can continue.

DO NOT OPERATE ARM WITHOUT BREAK-AWAY SENSORS FUNCTIONING.

2 Ft Coupler Installation (Required)

2 Ft Coupler is included in the kit and **MUST** be installed on your chosen arm to **add stiffness** when arm is cycling. It will also help strengthen the arm when it gets knocked out of the guide rollers. It doesn't prevent the arm from damage in all circumstances, but will help protect the arm against minor contact.



Drawings NOT to scale

If Shortening Arm see page 13

14 Ft 2-Piece Octagon Arm Assembly

DoorKing Part Number


1601-567

14 Ft 2-Piece Octagon Arm Kit

This kit is designed for use on a 1601 barrier gate operator **ONLY**. It has TWO 7 ft arm sections that assemble into a 14 ft arm.

A reverse edge **SHOULD** be installed on this arm. It is sold separately but **highly recommended** for safety, see next page.

Assemble 2-Piece Arm



If Shortening Arm see page 13


1601-269-U-3-26

Reverse Edge - Reverse/LED Edge Installation

These kits are designed to install on a **Break-Away** 14 ft 1-piece or 2-piece and a 17 ft **OCTAGON** arm (14 ft arm can be shortened if desired) on a 1601 or 1602 barrier gate operator. They **CANNOT** be used on a 1603 auto-spikes, 1620 lane barrier or 1625 wedge barrier operators.

Note: DO NOT operate arm with a malfunctioning reverse edge.

Installation



Remove End Cap: Push a screwdriver through hole in bottom of end cap to release spring **while** pulling cap **OFF**.

Re-install End Cap: Push a screwdriver through the hole in cap to release spring **while** pushing cap **ON**. Keep pushing cap on until a "**CLICK**" is heard which locks it in place.


FIRST Slide on Stopper

Stopper MUST be used or edge can slide in slot.

Loosen set screws.

.... THEN Slide on Edge

Tip: Liquid soap will help reverse edge slide on easier.



Operator End of Arm

After re-installing the end cap, push stopper up against the edge and tighten set screws to **LOCK** edge in place.

If Shortening a 14-ft Arm see page 13

MALE Plug connects to the 8080-356 wire harness. see page 8.

14 Ft Rubber Bumper Installation



This rubber bumper is designed to install on a 14 ft 1-piece or 2-piece **octagon arm** (not included) for a 1601, 1603 auto-spikes, 1620 lane barrier or a 1625 wedge barrier gate operator. It **CANNOT** be used on a 1602 operator. It offers **MINIMAL** safety protection.

Installation

Drawings NOT to scale

1 Remove End Cap

Push a screwdriver through hole in bottom of end cap to release spring **while** pulling cap off.



2 Slide on Rubber Bumper

The 3" trim end **MUST** side on first and it fits into the cover, see cover illustration.

Tip: Liquid soap will help rubber bumper slide on easier.

3 Reinstall End Cap

Push a screwdriver through the hole in cap to release spring **while** pushing cap on. Keep pushing cap on until a "**CLICK**" is heard which locks it in place.

3" trim end **MUST** be on the operator end as shown.

If using a shortened arm rubber bumper can be cut to length

Reverse Edge

- (Arm cut to 7 ft) **5 ft Reverse edge** P/N 8080-605
- (Arm cut to 8 ft) **6 ft Reverse edge** P/N 8080-606
- (Arm cut to 11 ft) **9 ft Reverse edge** P/N 8080-609
- (14 ft Arm) **12 ft Reverse edge** P/N 8080-612

Reverse/LED Edge

- (Arm cut to 7 ft) **5 Reverse/LED edge** P/N 8080-905
- (Arm cut to 8 ft) **6 ft Reverse/LED edge** P/N 8080-906
- (Arm cut to 11 ft) **9 ft Reverse/LED edge** P/N 8080-909
- (14 ft Arm) **12 ft Reverse/LED edge** P/N 8080-912

Shortening a 14-Ft Octagon Arm to 7-Ft, 8-Ft, 11-Ft


A 14 ft 1-piece **OR** 2-piece arm can be shortened to fit **different** length reverse edges. The shortened arm lengths are shown **depending on the length of the reverse edge chosen**. Follow the diagrams below depending on which style arm you have selected to shorten.

Note: Reverse edges **CANNOT** be cut down. They **MUST** remain intact.

Drawings NOT to scale

1-Piece 14 Ft Arm (P/N 1601-555)


2 ft coupler fits inside arm and flush with end **AFTER** cutting arm down.



2-Piece 14 Ft Arm (P/N 1601-567)


See page 10 for arm assembly

2 ft coupler fits inside arm and flush with end **AFTER** cutting arm down.



Drill a .375" Pivot Hole AFTER Shortening Arm

AFTER cutting down arm to your chosen length, use the 2-ft coupler's holes to align and drill a **NEW .375" hole** thru the top and bottom of the arm, depending on which **pivot point** you have chosen (see page 4). Slide coupler into end of arm and align the chosen coupler hole with the **NEW** drilled hole in arm. Reverse edge or bumper can now be installed on arm.



17 Ft Octagon Arm Assembly for a 1602 ONLY

DoorKing Part Numbers:

1602-303

Octagon Arm 3-ft Extension Kit

8080-915


15-ft Reverse Edge + Red/Green LED

(Sold Separately

See page 11)

This kit is designed for a **1602** barrier gate operator **ONLY**. It **CANNOT** be used on a 1601 OR 1603 auto-spikes. It will extend a 14 ft octagonal arm an **extra three feet**. The 15 ft reverse edge is sold separately but **HIGHLY recommended** for safety when lowering this **very long arm**.

Installation





Install End Cap in Arm Extension

Push a screwdriver through the hole in cap to release spring **while** pushing cap on. Keep pushing cap on until a **"CLICK"** is heard, locking it in place.

Older Existing Arm Cover

Older existing plastic arm cover will need to have a notch cut out for a **OCTAGON** Arm's **Reverse Edge**. Only one side of the cover will need to be cut out depending on which side of the operator the arm is mounted on. Use this template as a guide to remove material from the cover.



Make sure your printer is set to 100% (Actual Size)
Drawing to scale