# DKProx or Mifare USB PC Card Identifiers

DKProx Card Identifier can only read **DK Prox Cards** using the **DK Prox Card Identifier software**.

Mifare Card Identifier can only read **Mifare Cards** using the **Mifare Card Identifier software**.

Installation

Connect one end of cable to the card reader and plug the USB connector into the USB port on your computer.

USB

Your PC

Wave the card above the reader to read card code. LED will flash.

Download Software

Go to DoorKing's website (**www.doorking.com**) to DKProx card reader **OR** Mifare card reader to download **specific** software to your PC (not for Mac) depending on which type of card identifier you have chosen. The DKProx software **can not** read a Mifare card and vice-versa.
The APP is **NOT** available for smartphones.

1815-665-C-1-20