

1815-305 Mid-Range Card Reader



Mount the card reader using the plastic spacer and hardware provided as shown in the diagram below. Mount the spacer to the mounting post (mounting surface) first, then mount the card reader.

Read range will be substantially reduced if the reader is installed on metal surfaces without the spacer. Read range can also be affected by RF interference from power supplies, electrical and electronic equipment, some types of lighting, computers and monitors, motors and generators.

