
9050 and 9100 Fail-Secure Manual Release Kit

2600-862

Converts **Fail-Safe** manual release models 9050 and 9100 slide gate operators to a **Fail-Secure** manual release. Power outages or turning power off **WILL NOT** allow gate to be manually operated without physically unlocking the slide gate operator with the key first. The slide gate operator "Fails" (Loss of AC power) in a "Secure" (Manually in-operable) condition. This option is **typically used in UL 325 Class III and Class IV applications**.



· When reinstalling solenoid lock, existing mounting holes may need to be

elongated to allow retracted lock to clear clutch plate stops.