

ProxPlus® and Mifare USB Card Scanners

DoorKing Part Numbers

1815-692

ProxPlus Card Scanner

1815-690


Mifare Card Scanner

ProxPlus® Card Scanner can only read **ProxPlus Secure Cards** using the **ProxPlus/Mifare Card Scanner Software**.

Mifare Card Scanner can read **Mifare Classic 4 or 7 byte UID Cards** using the **ProxPlus/Mifare Card Scanner Software**.

Installation

Connect one end of cable to the card reader and plug the USB connector into the USB port on your computer.



Place the card on the card scanner to read card code. LED will flash.

Download Software

Go to the DoorKing web site **Access Card Scanners and Software page** to download the ProxPlus/Mifare Card Scanner Software (for PCs only).

The APP is **NOT** available for smartphones.