



- Good Channel: 4, 9, E** These channels are outside of the 22 MHz bandwidth of the most widely used WiFi router channels (IEEE 802.11 channels 1, 6, 11)
- OK Channel: 1-3, A-D** A fewer number of WiFi routers are defaulted to IEEE 802.11 channels 1 and 11
- Try to Avoid: 5-8** Most WiFi routers come from the factory defaulted to IEEE 802.11 channel 6, which could cause interference with DKS channels 5-8
- Do Not Use: 0, F** Because these channels are on the edge of the frequency band, their power settings are cut in half automatically